MAGUIRE ®

Intelligent Simplicity

VERSION #0617 1850

TECHNICAL MODEL DATASHEET

WSB 1850 Gravimetric Blender

High consistent accuracy on every material

For high output extruders and large central blending systems up to 3,075 lb/hr (1,400 kg/hr).

Wide range of settings

Each material is dosed by a stainless steel slide gate. The slide gate is capable of dosing a wide range of settings, from as little as 1% to 100%, based on an average density free flowing material (0.65).

Slide gate restrictor

For low percentage settings (1% - 4%) a slide gate restrictor (SGR-1) is recommended to restrict the opening of the gate by 50%. This reduces flow and enhances control.

WSB 1800 Series

The WSB 1850 has 1 hopper with 5 material compartments. Ideal for high output extruders and large central blending systems and for throughputs up to 3,075 lb/hr (1,400 kg/hr).

Batch size

The hoppers are mounted above the weigh bin with a default 40 lb (18 kg) batch size.

High consistent accuracy

On every material within ± 0.1% on a 1% setting.

Sequential dispensing

The system tares the weight of the weigh bin and then each material is dispensed – Regrind, Natural, Color and Additive – in sequence to ensure accurate dispenses of every material within the blend.

Homogenous mix

A complete batch is released into the mixing chamber and mixed with the previous batch to ensure a homogenous mix.

Control of the mix

Material blending is controlled by a level sensor mounted in the upper part of the mix chamber to retain accurate mixing. When the sensor is covered, the blender will not dispense any further batches.

Easy set up

Settings are made easily by either user friendly thumbwheels or entering settings directly on the keypad / optional touchscreen.

Password protection

Special functions can be easily accessed and set via the password protect key.



Audible and visual alarms

An audible and visual alarm sounds should a batch be incomplete.

Reporting

Setup and operation reports can be printed direct to a USB key. Alternatively, data is also available via Ethernet or serial ports allowing remote access and monitoring.

Integration

Integration to other control or ERP systems can be made via leading fieldbus or OPC interfaces.

Quick cleanout

A compressed air gun is provided for quick cleanout.

Rapid color change

Easy access to all material contact surfaces of the machine including hoppers, weigh bin and mixing chamber allows for rapid color changes without the use of tools.


Controller


The Maguire controller monitors and confirms the weight of each ingredient and comes with an optional touchscreen.






WSB 1850 Gravimetric Blender Dimensions






Compartment 1 - 6.6 cu ft [185 Litres] Compartments 3 & 4 - 3.3 cu ft [92 Litres] Compartments 2 & 7 - 2.5 cu ft [70 Litres]



¼" [6.4] Steel Plate

LID TOP VIEW



Technical data

M- 4-1 WOD 4050	
Model WSB 1850	
Maximum Throughput*	1,100kg/h to 1,400kg/h
	2,460lb/h to 3,075lb/h
Number of Materials	5
Material Dispense Systems	1- 3"x6" Slide Gate
	4- 2"x3" Slide Gate
Weight	295kg 650lb
Power Supply	120vac - 8.5 Amp
	230vac - 2.7 Amp
	415vac - 1.1 Amp
Operating Air Pressure	4-6 Bar 60-90psi
Air Consumption	0.3 m³/hr 0.17cfm
Shipping Weight	835Kg 1840lb
H x W x D	157 x 140 x 80cm
	62 x 55 x 31.5in

^{*}Throughput achieved is influenced by number of materials, how well they flow, vibration and loading consistency - each can effect maximum output of a blender, which in turn effects sizing the correct blender required for an application.

Key features

- Ideal for large processing machines
- Reduced weight and footprint
- Overall precision of ±0.1% of specified blend
- Compressed air gun for quick cleanout included
- Easy access to all material contact surfaces of the machine including hoppers, weigh bin, and mixing chamber permits rapid colour change without the use of tools
- Proprietary microprocessor-control technology monitors and confirms the weight of each ingredient / touch-screen optional.
- Compensation is made when a variation in dispense weight is detected
- Vibration Weighing management
- Improved documentation capabilities
- 5 Year Warranty





 $Maguire\ reserves\ the\ right\ to\ cancel\ product\ or\ change\ product,\ product\ specifications\ and\ data\ without\ notice\ to\ improve\ reliability,\ function,\ design\ or\ otherwise.$

MAGUIRE WORLDWIDE DISTRIBUTION LOCATIONS



F: +1 610 459 2700 E: info@maguire.com **Maguire Canada** Ontario, Canada

T: +1 905 879 1100 F: +1 905 879 1101 E: info@maguirecanada.com

Maguire Europe Staffordshire, UK

T: +44 1827 338 280 F: +44 1827 338 285 E: info@maguire-europe.com **Maguire IMEA**

Dubai, UAE T: +971 4 881 6700 E: info@maguire-imea.com

Maguire Asia

Singapore T: +65 6848 7117 F: +65 6542 8577

E: magasia@maguire-products.com.sg

Maguire China Shanghai T: +86 21 5882 3410

F: +86 21 5882 3420 E: amber@maguirechina.com